

# Panasonic

## Operating Instructions

### Digital Cordless Phone

Model No. **KX-TG7301E**

**KX-TG7302E**

**KX-TG7303E**

**KX-TG7304E**

### Digital Cordless Answering System

Model No. **KX-TG7321E**

**KX-TG7322E**

**KX-TG7323E**

**KX-TG7324E**



Model shown is KX-TG7301.

This unit is compatible with Caller ID. You must subscribe to the appropriate service offered by your service provider/telephone company.

**Charge the batteries for about 7 hours before initial use.**

Please read these operating instructions before using the unit and save them for future reference.

**Table of Contents**

<b>Introduction</b>	
Product information . . . . .	3
Accessory information . . . . .	5
For your safety . . . . .	7
Important safety instructions . . . . .	8
For best performance . . . . .	8
<b>Preparation</b>	
Controls . . . . .	11
Display . . . . .	12
Connections . . . . .	13
Battery installation and replacement . . . . .	14
Battery charge . . . . .	15
Wall mounting . . . . .	16
Symbols used in these operating instructions . . . . .	16
Turning the power on/off . . . . .	17
Setting up the unit before use . . . . .	17
<b>Making/Answering Calls</b>	
Making calls . . . . .	18
Answering calls . . . . .	18
Useful features during a call . . . . .	19
Key lock . . . . .	20
<b>Phonebook</b>	
Handset phonebook . . . . .	21
Copying phonebook entries . . . . .	22
<b>Programming</b>	
Programmable settings . . . . .	23
Special instructions for programmable settings . . . . .	25
Registering a unit . . . . .	26
<b>Caller ID Service</b>	
Using Caller ID service . . . . .	28
Caller list . . . . .	28
<b>Answering System</b>	
Answering system . . . . .	30
Turning the answering system on/off . . . . .	30
Greeting message . . . . .	31
Listening to messages using the base unit . . . . .	31
Listening to messages using the handset . . . . .	32
Remote operation . . . . .	33
Answering system settings . . . . .	34
<b>Voice Mail Service</b>	
Voice mail service . . . . .	36
<b>Intercom/Locator</b>	
Intercom . . . . .	37
Transferring calls . . . . .	37
Conference calls . . . . .	38
Handset locator . . . . .	38
<b>Useful Information</b>	
Character entry . . . . .	39
Error messages . . . . .	41
Troubleshooting . . . . .	42
Specifications . . . . .	47
Conditions of guarantee . . . . .	48
<b>Index</b>	
Index . . . . .	49

**Introduction**

**Product information**

Thank you for purchasing a Panasonic digital cordless phone.

**Important:**

- The suffix (E) in the following model numbers will be omitted in these instructions:  
 KX-TG7301E/KX-TG7302E/KX-TG7303E/KX-TG7304E/  
 KX-TG7321E/KX-TG7322E/KX-TG7323E/KX-TG7324E

**General information**

- This equipment is designed for use on the UK and Republic of Ireland analogue telephone network.
- In the event of problems, you should contact your equipment supplier in the first instance.

**Declaration of Conformity:**

- Panasonic Communications Co., Ltd. declares that this equipment is in compliance with the essential requirements and other relevant provisions of Radio & Telecommunications Terminal Equipment (R&TTE) Directive 1999/5/EC.

Declarations of Conformity for the relevant Panasonic products described in this manual are available for download by visiting:


<http://www.doc.panasonic.de>

**Contact to Authorised Representative:**

Panasonic Testing Centre  
 Panasonic Marketing Europe GmbH  
 Winsbergring 15, 22525 Hamburg, Germany

**Notable differences between the models**

**KX-TG7301 series**



- Model shown is KX-TG7304.

Model No.	Base unit	Handset	Quantity
	Part No.	Part No.	
KX-TG7301	KX-TG7301	KX-TGA730	1
KX-TG7302	KX-TG7301	KX-TGA730	2
KX-TG7303	KX-TG7301	KX-TGA730	3
KX-TG7304	KX-TG7301	KX-TGA730	4

## Introduction



### KX-TG7321 series



• Model shown is KX-TG7324.

Model No.	Base unit	Handset	
	Part No.	Part No.	Quantity
KX-TG7321	KX-TG7321	KX-TGA731	1
KX-TG7322	KX-TG7321	KX-TGA731	2
KX-TG7323	KX-TG7321	KX-TGA731	3
KX-TG7324	KX-TG7321	KX-TGA731	4

### Feature differences

Model No.	Answering system	Intercom
		 ↔  *1
KX-TG7301	–	● *2
KX-TG7302	–	●
KX-TG7303	–	●
KX-TG7304	–	●
KX-TG7321	●	● *2
KX-TG7322	●	●
KX-TG7323	●	●
KX-TG7324	●	●

\*1 Intercom calls can be made between the handsets.

\*2 Intercom calls can be made between the handsets by purchasing and registering one or more optional handsets (page 6).

**Introduction**


**Accessory information**

**Supplied accessories**

No.	Accessory item/ Part number	Quantity			
		KX-TG7301 KX-TG7321	KX-TG7302 KX-TG7322	KX-TG7303 KX-TG7323	KX-TG7304 KX-TG7324
①	AC adaptor for base unit/ PQLV207EU (PQLV207E)	1	1	1	1
②	Telephone line cord	1	1	1	1
③	Rechargeable batteries*1	2	4	6	8
④	Handset cover*2	1	2	3	4
⑤	Charger	—	1	2	3
⑥	AC adaptor for charger/ PQLV209EU (PQLV209E)	—	1	2	3

\*1 See page 5 for replacement battery information.

\*2 The handset cover comes attached to the handset.



**Additional/replacement accessories**

Please contact your nearest Panasonic dealer for sales information.

No.	Accessory item	Model number
①	DECT repeater	KX-A272

**Replacement battery information:**

- Replace batteries only with a nickel metal hydride (Ni-MH) type of battery. This model requires 2 AAA (R03) batteries for every handset. For best performance, we recommend using Panasonic rechargeable batteries (Model No. P03P or HHR-4MRE).
- Replacement batteries may have a different capacity from that of the supplied batteries.

## Introduction

### Expanding your phone system

You can expand your phone system by registering optional handsets (max. 6) to a single base unit.

**Handset (optional): KX-TGA731E**



### Sales and support information

#### Customer Care Centre

- For customers within the UK: 0844 844 3898
- For customers within the Republic of Ireland: 01289 8333
- Visit our website for product information: [www.panasonic.co.uk](http://www.panasonic.co.uk)
- E-mail: [customer.care@panasonic.co.uk](mailto:customer.care@panasonic.co.uk)

#### Direct Sales at Panasonic UK

- Order accessory and consumable items for your product with ease and confidence by phoning our Customer Care Centre Monday - Thursday 9:00am - 5:30pm, Friday 9:30am - 5:30pm (Excluding public holidays).
- Or go on line through our Internet Accessory ordering application at [www.panasonic.co.uk](http://www.panasonic.co.uk)
- Most major credit and debit cards accepted.
- All enquiries transactions and distribution facilities are provided directly by Panasonic UK Ltd.
- It couldn't be simpler!
- Also available through our Internet is direct shopping for a wide range of finished products, take a browse on our website for further details.

**Introduction**

**For your safety**

To prevent severe injury and loss of life/property, read this section carefully before using the product to ensure proper and safe operation of your product.

**WARNING**

**Power connection**

- Use only the power source marked on the product.
- Do not overload power outlets and extension cords. This can result in the risk of fire or electric shock.
- Completely insert the AC adaptor/power plug into the power outlet. Failure to do so may cause electric shock and/or excessive heat resulting in a fire.
- Regularly remove any dust, etc. from the AC adaptor/power plug by pulling it from the power outlet, then wiping with a dry cloth. Accumulated dust may cause an insulation defect from moisture, etc. resulting in a fire.
- Unplug the product from power outlets if it emits smoke, an abnormal smell, or makes an unusual noise. These conditions can cause fire or electric shock. Confirm that smoke has stopped emitting and contact an authorised service centre.
- Never touch the plug with wet hands. Danger of electric shock exists.

**Installation**

- To prevent the risk of fire or electrical shock, do not expose the product to rain or any type of moisture.
- Do not place or use this product near automatically controlled devices such as automatic doors and fire alarms.

Radio waves emitted from this product may cause such devices to malfunction resulting in an accident.

**Operating safeguards**

- Unplug the product from power outlets before cleaning. Do not use liquid or aerosol cleaners.
- Do not disassemble the product.
- Do not spill liquids (detergents, cleansers, etc.) onto the telephone line cord plug, or allow it to become wet at all. This may cause a fire. If the telephone line cord plug becomes wet, immediately pull it from the telephone wall jack, and do not use.

**Medical**

- Consult the manufacturer of any personal medical devices, such as pacemakers or hearing aids, to determine if they are adequately shielded from external RF (radio frequency) energy. (The product operates in the frequency range of 1.88 GHz to 1.90 GHz, and the RF transmission power is 250 mW (max.)
- Do not use the product in health care facilities if any regulations posted in the area instruct you not to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

**CAUTION**

**Installation and relocation**

- Never install telephone wiring during an electrical storm.
- Never install telephone line jacks in wet locations unless the jack is specifically designed for wet locations.

### Introduction

- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.
- The AC adaptor is used as the main disconnect device. Ensure that the AC outlet is installed near the product and is easily accessible.
- This product is unable to make calls when:
  - the handset batteries need recharging or have failed.
  - there is a power failure.
  - the key lock feature is turned on.

### Battery

- We recommend using the batteries noted on page 5. **USE ONLY rechargeable Ni-MH batteries AAA (R03) size.**
- Do not mix old and new batteries.
- Do not open or mutilate the batteries. Released electrolyte from the batteries is corrosive and may cause burns or injury to the eyes or skin. The electrolyte may be toxic if swallowed.
- Exercise care when handling the batteries. Do not allow conductive materials such as rings, bracelets or keys to touch the batteries, otherwise a short circuit may cause the batteries and/or the conductive material to overheat and cause burns.
- Charge the batteries provided with or identified for use with this product only, in accordance with the instructions and limitations specified in this manual.
- Only use a compatible base unit (or charger) to charge the batteries. Do not tamper with the base unit (or charger). Failure to follow these

instructions may cause the batteries to swell or explode.

## Important safety instructions

When using your product, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

1. Do not use this product near water for example, near a bathtub, washbowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
2. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
3. Do not use the telephone to report a gas leak in the vicinity of the leak.
4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

### SAVE THESE INSTRUCTIONS

## For best performance

### Base unit location/avoiding noise

The base unit and other compatible Panasonic units use radio waves to communicate with each other.

- For maximum coverage and noise-free communications, place your base unit:
  - at a convenient, high, and central location with no obstructions



## Introduction

between the handset and base unit in an indoor environment.

- away from electronic appliances such as TVs, radios, personal computers, wireless devices or other phones.
- avoid facing radio frequency transmitters, such as external antennas of mobile phone cell stations (avoid putting the base unit on a bay window or near a window).
- Coverage and voice quality depends on the local environmental conditions.
- If the reception for a base unit location is not satisfactory, move the base unit to another location for better reception.

### Environment

- Keep the product away from electrical noise generating devices, such as fluorescent lamps and motors.
- The product should be kept free from excessive smoke, dust, high temperature, and vibration.
- The product should not be exposed to direct sunlight.
- Do not place heavy objects on the power cord or top of the product.
- When you leave the product unused for a long period of time, unplug the product from the power outlet.
- The product should be kept away from heat sources such as radiators, cookers, etc. It should not be placed in rooms where the temperature is less than 5 °C or greater than 40 °C. Damp basements should also be avoided.
- The maximum calling distance may be shortened when the product is used in the following places: Near obstacles such as hills, tunnels, underground, near metal objects such as wire fences, etc.

- Operating the product near electrical appliances may cause interference. Move away from the electrical appliances.

### Routine care

- **Wipe the outer surface of the product with a soft moist cloth.**
- Do not use benzine, thinner, or any abrasive powder.


### Notice for product disposal, transfer, or return

- This product can store your private/confidential information. To protect your privacy/confidentiality, we recommend that you erase the information such as phonebook or caller list entries from the memory before you dispose of, transfer, or return the product.

### Information on Disposal for Users of Waste Electrical & Electronic Equipment (private households)



This symbol on the products and/or accompanying documents means that used electrical and electronic products should not be mixed with general household waste. For proper treatment, recovery and recycling, please take these products to designated collection points, where they will be accepted on a free of charge basis. Alternatively, in some countries you may be able to return your products to your local retailer upon the purchase of an equivalent new product. Disposing of this product correctly will help to save valuable resources and prevent any potential negative effects on



### **Introduction**

human health and the environment which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point.

Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.





### **For business users in the European Union**

If you wish to discard electrical and electronic equipment, please contact your dealer or supplier for further information.

### **Information on Disposal in other Countries outside the European Union**

This symbol is only valid in the European Union.

If you wish to discard this product, please contact your local authorities or dealer and ask for the correct method of disposal.




**Preparation**

**Controls**

**Base unit**


■ KX-TG7301/KX-TG7302/  
KX-TG7303/KX-TG7304



- 1 Charge contacts
- 2 [📶] (Locator)

**Base unit**


■ KX-TG7321/KX-TG7322/  
KX-TG7323/KX-TG7324



- 1 Charge contacts
- 2 Speaker
- 3 [■] (Stop)
- 4 [X] (Erase)
- 5 [▲] (Volume up)  
[▼] (Volume down)  
[↶] (Repeat)  
[↷] (Skip)

- 6 [▶] (Play)  
Message indicator
- 7 [📶] (Locator)
- 8 [📞] (Answer on)  
Answer on indicator

**Handset**




- 1 Speaker
- 2 Soft keys
- 3 [📞] (Talk)
- 4 [📞] (Speakerphone)
- 5 Dial keypad
- 6 [R/Ⓜ] (R: Recall/Flash  
Ⓜ: Alarm shortcut key)
- 7 Charge indicator  
Ringer indicator
- 8 Receiver
- 9 Display
- 10 [🔌] (Off/Power)
- 11 Navigator key ([▲]/[▼]/[◀]/[▶])  
◀ (Volume: [▲]/[▼])
- 12 [C/🔇] (Clear/Mute)
- 13 [INT] (Intercom)
- 14 Microphone
- 15 Charge contacts

## Preparation

### Using the navigator key


The handset navigator key can be used to navigate through menus and to select items shown on the display by pressing **[▲]**, **[▼]**, **[←]**, or **[→]**.

To adjust the receiver or speaker volume, press **[▲]** to increase the volume, or press **[▼]** to decrease the volume repeatedly while talking.



### Soft keys

The handset features 3 soft keys. By pressing a soft key, you can select the feature shown directly above it on the display.



## Display

### Handset display items

Item	Meaning
	Within range of a base unit <ul style="list-style-type: none"> <li>When flashing: Handset is searching for base unit. (page 44)</li> </ul>

Item	Meaning
	Handset is accessing base unit. (intercom, paging, changing base unit settings, etc.)
	Handset is on an outside call.
	Missed call* <sup>1</sup> (page 28)
	<ul style="list-style-type: none"> <li>When displayed next to the battery icon: Answering system is on.*<sup>2</sup> (page 30)</li> <li>When displayed with a number: New messages have been recorded.*<sup>2</sup> (page 32)</li> </ul>
	Answering system is full.* <sup>2</sup>
	Answering system answers calls with a greeting message and caller messages are not recorded.* <sup>2</sup> ("Caller's recording time", page 35)
	Battery level
	Alarm is on. (page 25)
	Call privacy mode is on. (page 19)
	Ringer volume (page 23) is off.
	New voice mail message received* <sup>3</sup> (page 36)
<b>IN USE</b>	<ul style="list-style-type: none"> <li>Someone is using the line.</li> <li>Answering system is being used by another handset or the base unit.*<sup>2</sup></li> </ul>

## Preparation

- \*1 Caller ID subscribers only
- \*2 KX-TG7321/KX-TG7322/  
KX-TG7323/KX-TG7324
- \*3 Voice mail subscribers only

### Soft key icons

Icon	Action
	Returns to the previous screen.
	Displays the menu.
	Accepts the current selection.
	Displays a previously dialled phone number.
	Opens the phonebook.
	Displays the character entry mode for phonebook search. (page 21) <sup>*1</sup>
	Turns the key lock feature off. (page 20)
	Selects a character entry mode.
	Stops recording or playback. <sup>*1</sup>
	Inserts a dialling pause.
	Erases the selected item.
	No function


- \*1 KX-TG7321/KX-TG7322/  
KX-TG7323/KX-TG7324

## Connections

Connect the AC adaptor cord (1) by pressing the plug firmly (2). Connect the telephone line cord until it clicks into the base unit and telephone line jack (3).

### Base unit


- Use only the supplied Panasonic AC adaptor PQLV207E.
- Use only the supplied telephone line cord. Using another telephone line cord may not allow the unit to work properly.



### Charger

**Available for:**  
KX-TG7302/KX-TG7303/  
KX-TG7304/KX-TG7322/  
KX-TG7323/KX-TG7324

- Use only the supplied Panasonic AC adaptor PQLV209E.



### Note:

- The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.)
- The AC adaptor should be connected to a vertically oriented or floor-

### Preparation

mounted AC outlet. Do not connect the AC adaptor to a ceiling-mounted AC outlet, as the weight of the adaptor may cause it to become disconnected.


#### During a power failure

The unit will not work during a power failure. We recommend connecting a corded-type telephone (without AC adaptor) to the same telephone line or to the same telephone line jack using a T-adaptor. Your Panasonic sales shop can offer you more information about connection possibilities.

#### If you subscribe to a DSL/ADSL service

Please attach a DSL/ADSL filter (contact your DSL/ADSL provider) to the telephone line between the base unit and the telephone line jack in the event of the following:

- noise is heard during conversations.
- Caller ID features do not function properly.




## Battery installation and replacement


#### Important:

- Use the supplied rechargeable batteries (Part No. HHR-55AAAB).
- When installing the batteries:

- Wipe the battery ends (+, -) with a dry cloth.
- Avoid touching the battery ends (+, -) or the unit contacts.
- Confirm correct polarities (+, -).
- When replacing the batteries:
  - USE ONLY rechargeable Ni-MH batteries AAA (R03) size.
  - Do NOT use Alkaline/Manganese/ Ni-Cd batteries.
  - We recommend using the Panasonic rechargeable batteries noted on page 5, 8.
- 1 Firmly press the notch on the handset cover and slide it in the direction of the arrow.



- 2 Insert the batteries negative (-) end first. Close the handset cover.




#### Important:

- If the handset does not automatically turn on after installing/replacing batteries, press **[\*][0]** for about 1 second, or place the handset on the base unit or charger.

**Preparation**

**Note:**

- When replacing batteries, remove the old batteries.




**Battery charge**

Place the handset on the base unit or charger for about 7 hours before initial use.

- While charging, “Charging” is displayed and the charge indicator on the handset lights up. When the batteries are fully charged, “Charge Completed” displays. The charge indicator stays lit even after the batteries are fully charged.

Base unit\*1

Charger\*2



\*1 Model shown is KX-TG7301.

\*2 KX-TG7302/KX-TG7303/  
KX-TG7304/KX-TG7322/  
KX-TG7323/KX-TG7324

**Note:**

- It is normal for the handset to feel warm during charging.
- If you want to use the unit immediately, charge the batteries for at least 15 minutes.
- Clean the charge contacts of the handset, base unit, and charger with a soft, dry cloth once a month. Clean more often if the unit is exposed to grease, dust, or high humidity.

**Battery level**

Battery icon	Battery level
	High
	Medium
	Low • When flashing: Needs charging.

**Panasonic Ni-MH battery performance (supplied batteries)**

Operation	Operating time
In continuous use	17 hours max.
Not in use (standby)	150 hours max.

**Note:**



- It is normal for batteries not to reach full capacity at the initial charge. Maximum battery performance is reached after a few complete cycles of charge/discharge (use).
- Actual battery performance depends on a combination of how often the handset is in use and how often it is not in use (standby).
- Even after the handset is fully charged, the handset can be left on the base unit or charger without any ill effect on the batteries.

### Preparation

- The battery level may not be displayed correctly after you replace the batteries. In this case, place the handset on the base unit or charger and let it charge for at least 7 hours.



## Wall mounting

### Base unit



### Charger

**Available for:**  
 KX-TG7302/KX-TG7303/  
 KX-TG7304/KX-TG7322/  
 KX-TG7323/KX-TG7324



## Symbols used in these operating instructions

Symbol	Meaning
[ ]	The words in the brackets indicate button names on the handset and base unit. <b>Example:</b> Unit keys: [↶], [↷⊕]
→	Proceed to the next operation.
“ ”	The words in quotations indicate the menu on the display. <b>Example:</b> “Auto Talk”
[▼]/[▲]: “ ”	Press [▼] or [▲] to select the words in quotations. <b>Example:</b> [▼]/[▲]: “Off”



**Preparation**

## Turning the power on/off

### Power on

Press **[\*][0]** for about 1 second.

### Power off

Press **[\*][0]** for about 2 seconds.

## Setting up the unit before use

### Display language

- 1 **[M]** (middle soft key)
- 2 **[v]/[^]**: "Handset Setup" → **OK**
- 3 **[v]/[^]**: "Display Setup" → **OK**
- 4 **[v]/[^]**: "Select Language" → **OK**
- 5 **[v]/[^]**: Select your desired language. → **OK** → **[\*][0]**

#### Note:

- If you select a language you cannot read: **[\*][0]** → **[M]** → **[^]** 2 times → **OK** → **[v]** 2 times → **OK** 2 times → **[v]/[^]**: Select your desired language. → **OK** → **[\*][0]**

### Date and time

- 1 **[M]** (middle soft key)
- 2 **[v]/[^]**: "Handset Setup" → **OK**
- 3 **[v]/[^]**: "Time Settings" → **OK**

- 4 **[v]/[^]**: "Set Date & Time" → **OK**
- 5 Enter the current date, month, and year.  
**Example:** 15 July, 2008  
**[1][5] [0][7] [0][8]**
- 6 Enter the current hour and minute.  
**Example:** 9:30 PM  
**[0][9] [3][0]** → Press **[\*]** until "09:30 PM" is displayed.
- 7 **OK** → **[\*][0]**

#### Note:

- To correct a digit, press **[<]** or **[>]** to move the cursor to the digit, then make the correction.
- The date and time may be incorrect after a power failure. In this case, set the date and time again.

## Making/Answering Calls

### Making calls

- 1 Lift the handset and dial the phone number.
  - To correct a digit, press **[C/⊗]**.
- 2 **[↶]**
- 3 When you finish talking, press **[⊗/⊙]** or place the handset on the base unit or charger.

### Using the speakerphone

- 1 Dial the phone number, and press **[⊗/⊙]**.
  - Speak alternately with the other party.
- 2 When you finish talking, press **[⊗/⊙]**.

#### Note:

- For best performance, use the speakerphone in a quiet environment.
- To switch back to the receiver, press **[↶]**.

### Adjusting the receiver or speaker volume

Press **[▲]** or **[▼]** repeatedly while talking.

### Making a call using the redial list

The last 10 phone numbers dialed are stored in the redial list (each 24 digits max.).

- 1 **[⊗/⊙]** (right soft key)
- 2 **[▼]/[▲]**: Select the desired phone number.
- 3 **[↶]**

### Erasing a number in the redial list

- 1 **[⊗/⊙]** (right soft key)
- 2 **[▼]/[▲]**: Select the desired phone number. → **[⊗/⊙]** → **OK**

- 3 **[▼]/[▲]**: "Yes" → **OK** → **[⊗/⊙]**

### Pause (for PBX/long distance service users)

A pause is sometimes required when making calls using a PBX or long distance service. When storing a calling card access number and/or PIN in the phonebook, a pause is also needed (page 22).

**Example:** If you need to dial the line access number "0" when making outside calls with a PBX:

- 1 **[0]** → **P**
- 2 Dial the phone number. → **[↶]**

#### Note:

- A 3 second pause is inserted each time **P** is pressed. Repeat as needed to create longer pauses.

### Answering calls

When a call is being received, the ringer indicator on the handset flashes.

- 1 Lift the handset and press **[↶]** or **[⊗/⊙]** when the unit rings.
  - You can also answer the call by pressing any dial key from **[0]** to **[9]**, **[\*]**, or **[#]**. (**Any key answer feature**)
- 2 When you finish talking, press **[⊗/⊙]** or place the handset on the base unit or charger.

### Auto talk

You can answer calls simply by lifting the handset off the base unit or charger. You do not need to press **[↶]**. To turn this feature on, see page 23.

## Making/Answering Calls

### Adjusting the handset ringer volume

Press **[▲]** or **[▼]** repeatedly to select the desired volume while the handset is ringing for an incoming call.

**Note:**

- You can also program the handset ringer volume beforehand (page 23).

### Useful features during a call

#### Mute

While mute is turned on, you can hear the other party, but the other party cannot hear you.

- 1 Press **[C/⊗]** during conversation.
- 2 To return to the conversation, press **[C/⊗]** again.

#### Recall/flash

**[R/⊗]** allows you to use the special features of your host PBX such as transferring an extension call, or accessing optional telephone services.

**Note:**

- To change the recall/flash time, see page 24.

### For call waiting or Call Waiting Caller ID service users

To use call waiting, you must first subscribe to the call waiting service of your service provider/telephone company.

This feature allows you to receive calls while you are already talking on the phone. If you receive a call while on the phone, you will hear a call waiting tone.

**If you subscribe to both Caller ID and Call Waiting with Caller ID services,**

the 2nd caller's information is displayed after you hear the call waiting tone on the handset.

- 1 Press **[R/⊗]** to answer the 2nd call.
- 2 To switch between calls, press **[R/⊗]**.

**Note:**

- Please contact your service provider/telephone company for details and availability of this service in your area.

#### Call share

This feature allows you to join an existing outside call.

To join the conversation, press **[↶]** when the other handset is on an outside call.

#### Call privacy

Call privacy allows you to prevent other users from joining your conversations with outside callers. To allow other users to join your conversations, leave this feature off. The default setting is "OFF".

- 1 Press **[⊞]** during an outside call.
- 2 **[▼]/[▲]**: Select the desired setting.  
→ **OK**
  - When this feature is turned on, **⊞** is displayed.


**Note:**



- This feature will turn off after you hang up the call.

## Making/Answering Calls

### Key lock

The handset can be locked so that no calls or settings can be made. Incoming calls can be answered, but all other functions are disabled while key lock is on.

To turn key lock on, press  (middle soft key) for about 3 seconds.

-  is displayed.
- To turn key lock off, press  (middle soft key) for about 3 seconds.

**Note:**

- Calls to emergency numbers cannot be made until key lock is turned off.

**Phonebook**

**Handset phonebook**

The phonebook allows you to make calls without having to dial manually. You can add 100 names and phone numbers.

**Adding entries**

- 1 (left soft key) →
- 2 **[v]/[Δ]**: "New Entry" → **OK**
- 3 Enter the party's name (16 characters max.; page 39). → **OK**
- 4 Enter the party's phone number (24 digits max.). → **OK** 2 times
  - To add other entries, repeat from step 3.
- 5 **[\*0]**

**Finding and calling a phonebook entry**

**Scrolling through all entries**

- 1 (left soft key)
- 2 **[v]/[Δ]**: Select the desired entry.
  - You can scroll through the phonebook entry by pressing and holding **[v]** or **[Δ]**.
- 3 **[↶]**

**Searching by first character (using a dial key) (KX-TG7321/KX-TG7322/KX-TG7323/KX-TG7324)**

- 1 (left soft key)
- 2 Press the dial key (**[0]** to **[9]**) which contains the character you are searching for (page 39).
  - Press the same dial key repeatedly to display the first entry corresponding to each character located on that dial key.

- If there is no entry corresponding to the character you selected, the next entry is displayed.
- To change the character entry mode:  
**ABC** → **[v]/[Δ]**: Select the character entry mode. → **OK**

- 3 **[v]/[Δ]**: Scroll through the phonebook if necessary.
- 4 **[↶]**

**Editing entries**

- 1 Find the desired entry (page 21). →
- 2 **[v]/[Δ]**: "Edit" → **OK**
- 3 Edit the name if necessary (16 characters max.; page 39). → **OK**
- 4 Edit the phone number if necessary (24 digits max.). → **OK** 2 times → **[\*0]**

**Erasing entries**

**Erasing an entry**

- 1 Find the desired entry (page 21). →
- 2 **[v]/[Δ]**: "Erase" → **OK**
- 3 **[v]/[Δ]**: "Yes" → **OK** → **[\*0]**


**Erasing all entries**

- 1 (left soft key) →
- 2 **[v]/[Δ]**: "Erase All" → **OK**
- 3 **[v]/[Δ]**: "Yes" → **OK**
- 4 **[v]/[Δ]**: "Yes" → **OK** → **[\*0]**

## Phonebook

### Chain dial

This feature allows you to dial phone numbers in the phonebook while you are on a call. This feature can be used, for example, to dial a calling card access number or bank account PIN that you have stored in the phonebook, without having to dial manually.

- 1 During an outside call, press .
- 2 **[v]/[▲]**: Select the desired entry.
- 3 Press **OK** to dial the number.

#### Note:


- When storing a calling card access number and your PIN in the phonebook as one phonebook entry, press **P** to add pauses after the number and PIN as necessary (page 18).

### Copying phonebook entries



**Available for:**  
KX-TG7321/KX-TG7322/KX-TG7323/  
KX-TG7324

You can copy phonebook entries to the phonebook of another compatible Panasonic handset.

#### Copying an entry

- 1 Find the desired entry (page 21).  
→ 
- 2 **[v]/[▲]**: "Copy" → **OK**
- 3 Enter the handset number you wish to send the phonebook entry to.
  - When an entry has been copied, "Completed" is displayed.
  - To continue copying another entry: **[v]/[▲]**: "Yes" → **OK**  
→ Find the desired entry. → **OK**
- 4 **[\*][0]**


#### Copying all entries

- 1  (left soft key) → 
- 2 **[v]/[▲]**: "Copy All" → **OK**
- 3 Enter the handset number you wish to send the phonebook entry to.
  - When all entries have been copied, "Completed" is displayed.
- 4 **[\*][0]**

**Programming****Programmable settings**

You can customise the unit by programming the following features using the handset.

**Programming by scrolling through the display menus**

- 1  (middle soft key)
- 2 Press [▼] or [▲] to select the desired top-menu. → **OK**
- 3 Press [▼] or [▲] to select the desired item in sub-menu 1. → **OK**
  - In some cases, you may need to select from sub-menu 2. → **OK**
- 4 Press [▼] or [▲] to select the desired setting. → **OK**
  - This step may vary depending on the feature being programmed.
  - To exit the operation, press [**⏏**].

**Note:**

- For other top-menus, please refer to each chapter.
- In the following table, < > indicates the default settings.
- The current item or setting is highlighted on the display.

Top-menu	Sub-menu 1	Sub-menu 2	Page
Handset Setup	Time Settings	Set Date & Time <sup>*1</sup>	17
		Alarm	25
		Time Adjustment <sup>*1</sup> <Caller ID[Auto]>	25
	Ringer Setup	Ringer Volume <Maximum>	–
		Ringtone <sup>*2, *3</sup> <Ringtone 1>	–
		Display Setup	Select Language <English>
		Contrast <Level 3>	–
	Register H.set (Register handset)	–	26
	Keytones <sup>*4</sup> <On>	–	–
	Auto Talk <sup>*5</sup> <Off>	–	18

### Programming

Top-menu	Sub-menu 1	Sub-menu 2	Page
Base Unit Setup <sup>*1</sup>	Ringer Volume <sup>*6</sup> <Medium>	–	–
	Recall/Flash <sup>*7</sup> <100 msec.>	–	19
	Base Unit PIN <0000>	–	26
	Repeater Mode <Off>	–	27

- \*1 If you program these settings using one of the handsets, you do not need to program the same item using another handset.
- \*2 If you select one of the melody ringer tones, the ringer tone continues to play for several seconds even if the caller has already hung up. You may either hear a dial tone or no one on the line when you answer the call.
- \*3 The preset melodies in this product are used with permission of © 2007 Copyrights Vision Inc.
- \*4 Turn this feature off if you prefer not to hear key tones while you are dialling or pressing any keys, including confirmation tones and error tones.
- \*5 If you subscribe to a Caller ID service and want to view the caller's information after lifting up the handset to answer a call, turn off this feature.
- \*6 KX-TG7321/KX-TG7322/KX-TG7323/KX-TG7324
- \*7 The recall/flash time depends on your telephone exchange or host PBX. Contact your PBX supplier if necessary.



## Special instructions for programmable settings

### Alarm

You can set one of 2 different alarm options (once or daily) at a time for each handset. An alarm sounds at the set time for 3 minutes.

#### Important:

- Set the date and time beforehand (page 17).

- 1 (middle soft key)
- 2 **[v]/[▲]**: "Handset Setup" → **OK**
- 3 **[v]/[▲]**: "Time Settings" → **OK**
- 4 **[v]/[▲]**: "Alarm" → **OK**
- 5 **[v]/[▲]**: Select the desired alarm option. → **OK**

<p><b>"Off"</b> Turns alarm off. Press <b>OK</b> again, then press <b>[*0]</b> to exit.</p>
<p><b>"Once"</b> An alarm sounds once at the set time. Enter the desired date and month.</p>
<p><b>"Daily"</b> An alarm sounds daily at the set time.</p>

- 6 Set the desired time. → **OK**
- 7 **[v]/[▲]**: Select the desired ringer tone. → **OK** 2 times
  - We recommend selecting a different ringer tone to the one used for outside calls.
  - When the alarm is set, 0 is displayed.
- 8 **[\*0]**

#### Note:

- You can skip to step 4 by pressing **[R/0]** in standby mode.
- To stop the alarm, press any dial key or place the handset on the base unit or charger.
- When the handset is in use, the alarm will not sound until the handset is in standby mode.
- If you select "Once", the setting changes to "off" after the alarm sounds.
- Even when the ringer volume for outside calls is set to off (page 23), the alarm sound is heard at a low level.

### Time adjustment (Caller ID subscribers only)

This feature allows the unit to automatically adjust the date and time each time caller information is received. To use this feature, your caller ID service has to provide caller information, including date and time. Contact your service provider/telephone company for details.

To turn this feature on, select "Caller ID [Auto]". To turn this feature off, select "Manual".

#### Important:

- To use this feature, set the date and time first (page 17).

- 1 (middle soft key)
- 2 **[v]/[▲]**: "Handset Setup" → **OK**
- 3 **[v]/[▲]**: "Time Settings" → **OK**
- 4 **[v]/[▲]**: "Time Adjustment" → **OK**
- 5 **[v]/[▲]**: Select "Caller ID [Auto]" or "Manual". → **OK** → **[\*0]**

## Programming

### Changing the base unit PIN (Personal Identification Number)

#### Important:

- If you change the PIN, please make note of your new PIN. The unit will not reveal the PIN to you. If you forget your PIN, see page 43.

- 1 (middle soft key)
- 2 **[v]/[▲]**: “Base Unit Setup” → **OK**
- 3 **[v]/[▲]**: “Base Unit PIN” → **OK**
- 4 Enter the current 4-digit base unit PIN (default: “0000”).
- 5 Enter the new 4-digit base unit PIN. → **OK** → **[\*0]**

handset is near the base unit), register the handset.

- 1 **Handset:**  
 (middle soft key)
- 2 **[v]/[▲]**: “Handset Setup” → **OK**
- 3 **[v]/[▲]**: “Register H.set” → **OK**
- 4 **Base unit:**  
Proceed with the operation for your model.
  - **KX-TG7301/KX-TG7302/ KX-TG7303/KX-TG7304**  
Press and hold **[\*]** for about 5 seconds. (No registration tone)
  - **KX-TG7321/KX-TG7322/ KX-TG7323/KX-TG7324**  
Press and hold **[\*]** for about 5 seconds, until the registration tone sounds.

- If all registered handsets start ringing, press the same button to stop. Then repeat this step.
- The next step should be completed within 90 seconds.

### Registering a unit

#### Operating additional units

##### Additional handsets

Up to 6 handsets can be registered to the base unit.

#### Important:

- The additional handset model recommended for use with this unit is noted on page 6. If another handset model is used, certain operations (handset settings, base unit settings, etc.) may not be available.

#### Registering a handset to the base unit

The supplied handset and base unit are pre-registered. If for some reason the handset is not registered to the base unit (for example, flashes even when the

- 5 **Handset:**  
Wait until “Enter Base PIN” is displayed. → Enter the base unit PIN (default: “0000”). → **OK**
  - If you forget your PIN, see page 43.
  - When the handset has been registered successfully, stops flashing.


#### Note:

- When you purchase an additional handset, refer to the additional handset’s installation manual for registration.

## Programming

### Deregistering a handset

A handset can cancel its own registration (or the registration of another handset) that is stored in the base unit. This allows the handset to end its wireless connection with the system.

- 1  (middle soft key)
- 2 **[v]/[^]**: "Base Unit Setup" → **OK**
- 3 **[3][3][5]**
- 4 **[v]/[^]**: "Deregistration" → **OK**
  - The numbers of all handsets registered to the base unit are displayed.
- 5 Select the handset(s) you want to cancel by pressing the desired handset number. → **OK**
  - The selected handset number(s) flashes.
  - To cancel a selected handset number, press the number again. The number stops flashing.
- 6 **[v]/[^]**: "yes" → **OK**
  - A confirmation tone sounds as each handset number disappears.
  - The handset does not beep when cancelling its own registration.

### 7

### Increasing the range of the base unit



You can increase the signal range of the base unit by using a DECT repeater. Please use only the Panasonic DECT repeater noted on page 5. Contact your Panasonic dealer for details.

#### Important:



- Before registering the repeater to this base unit, you must turn the repeater mode on.

- Do not use more than one repeater at a time.

### Setting the repeater mode

- 1  (middle soft key)
- 2 **[v]/[^]**: "Base Unit Setup" → **OK**
- 3 **[v]/[^]**: "Repeater Mode" → **OK**
- 4 **[v]/[^]**: Select the desired setting. → **OK** → 

#### Note:

- After turning the repeater mode on or off,  flashes on the handset momentarily. This is normal and the handset can be used once  stops flashing.

## Caller ID Service

### Using Caller ID service

#### Important:

- This unit is Caller ID compatible. To use Caller ID features, you must subscribe to a Caller ID service. Contact your service provider/telephone company for details.

#### Caller ID features

When an outside call is being received, the caller's phone number is displayed. Caller information for the last 50 callers is logged in the caller list from the most recent call to the oldest.

- If the unit cannot receive caller information, the following is displayed:
  - “**Out of Area**”: The caller dialed from an area which does not provide a Caller ID service.
  - “**Private Caller**”: The caller requested not to send caller information.
- If the unit is connected to a PBX system, caller information may not be properly received. Contact your PBX supplier.

#### Missed calls

If a call is not answered, the unit treats it as a missed call and **↔** is displayed. This lets you know if you should view the caller list to see who called while you were away.

Even if only one missed call in the caller list is viewed (page 28), **↔** disappears from the display. When you receive another new call, **↔** is displayed again.

#### Phonebook name display

When caller information is received and it matches a phone number stored in the phonebook, the stored name in the

phonebook is displayed and logged in the caller list.

### Caller list

#### Important:

- Only 1 person can access the caller list at a time.

#### Viewing the caller list and calling back

- 1 **[MFK]** (middle soft key)
- 2 **[v]/[▲]**: “**Caller List**” → **OK**
- 3 Press **[v]** to search from the most recent call, or press **[▲]** to search from the oldest call.
- 4 To call back, press **[↶]**. To exit, press **[X/O]**.

#### Note:



- If the item has already been viewed or answered, “**v**” is displayed, even if it was viewed or answered using another handset.
- To erase the item, press **[X]**. → **[v]/[▲]**: “**Yes**” → **OK**

#### Editing a caller's phone number before calling back



- 1 **[MFK]** (middle soft key)
- 2 **[v]/[▲]**: “**Caller List**” → **OK**
- 3 **[v]/[▲]**: Select the desired entry. → **[MFK]**
- 4 **[v]/[▲]**: “**Edit and Call**” → **OK**
- 5 Edit the number.
  - Press dial key (**[0]** to **[9]**) to add, **[C/⊗]** to delete.
- 6 **[↶]**

**Caller ID Service**

**Erasing caller information**

- 1  (middle soft key)
- 2 **[v]/[Δ]**: "Caller List" → **OK**
- 3 **[v]/[Δ]**: Select the desired entry.  
→ 
- 4 **[v]/[Δ]**: Select "Erase" or "Erase All". → **OK**
- 5 **[v]/[Δ]**: "Yes" → **OK** → **[X]**

**Storing caller information to the phonebook**

- 1  (middle soft key)
- 2 **[v]/[Δ]**: "Caller List" → **OK**
- 3 **[v]/[Δ]**: Select the desired entry.  
→ 
- 4 **[v]/[Δ]**: "Add Phonebook" → **OK**
- 5 To store the name, continue from step 3, "Adding entries", page 21.

## Answering System

### Answering system

**Available for:**  
KX-TG7321/KX-TG7322/KX-TG7323/  
KX-TG7324

The answering system can answer and record calls for you when you are unavailable to answer the phone. You can also set the unit to play a greeting message but not to record caller messages. Select "Greeting OnLy" as the recording time setting (page 35).

**Important:**

- Only 1 person can access the answering system (listen to messages, record a greeting message, etc.) at a time.
- When callers leave messages, the unit records the day and time of each message. Make sure the date and time have been set correctly (page 17).

### Memory capacity

The total recording capacity (including your greeting message) is about 20 minutes. A maximum of 64 messages can be recorded.

**Note:**

- If message memory becomes full:
  - "Answer Sys. Full" is shown on the handset display.
  - the answer on indicator on the base unit flashes rapidly when the answering system is turned on.
- When the message memory becomes full:
  - If you use the pre-recorded greeting message, the unit automatically switches to another pre-recorded greeting message asking callers to call again later.

- If you recorded your own greeting message, the same message is still announced to callers even though their messages are not recorded.

### Turning the answering system on/off

The answering system is preset to on.

#### Using the base unit

Press **[☐]** to turn on/off the answering system.

- When the answering system is turned on, the answer on indicator lights up.

#### Using the handset

- 1 **[☐]** (middle soft key)
- 2 **[▼]/[▲]**: "Answer System" → **OK**
- 3 **[▼]/[▲]**: Select "Answer On" or "Answer Off". → **OK** → **[\*0]**

**Note:**

- When the answering system is turned on, **[☐]** is displayed next to the battery icon.

### Call screening

While a caller is leaving a message, you can listen to the call through the handset's speaker. To adjust the speaker volume, press **[▲]** or **[▼]** repeatedly. You can answer the call by pressing **[☐]** on the handset. Call screening can be set for each handset.

**Note:**

- To turn this feature off, see page 35.



## Answering System

### Greeting message

When the unit answers a call, callers hear a greeting message. You can record your own greeting message or use a pre-recorded greeting message.

### Recording your greeting message


You can record your own greeting message (2 minutes and 30 seconds max.).

- 1  (middle soft key)
- 2 **[▼]/[▲]**: "Answer System" → **OK**
- 3 **[▼]/[▲]**: "Record Greeting" → **OK**
- 4 Hold the handset about 20 cm away and speak clearly into the microphone.
- 5 Press  to stop recording.
- 6 **[↶⊙]**

### Using a pre-recorded greeting message

If you erase or do not record your own greeting message, the unit plays a pre-recorded greeting message for callers and asks them to leave a message. If the message recording time (page 35) is set to "Greeting Only", caller messages are not recorded and the unit plays a different pre-recorded greeting message asking callers to call again.


### Playing back the greeting message

- 1  (middle soft key)
- 2 **[▼]/[▲]**: "Answer System" → **OK**

- 3 **[▼]/[▲]**: "Play Greeting" → **OK**
- 4 **[↶⊙]**

### Erasing your greeting message

If you erase your own greeting message, the unit plays a pre-recorded greeting message for callers.

- 1  (middle soft key)
- 2 **[▼]/[▲]**: "Answer System" → **OK**
- 3 **[▼]/[▲]**: "Erase Message" → **OK**
- 4 **[▼]/[▲]**: "Erase Greeting" → **OK**
- 5 **[▼]/[▲]**: "Yes" → **OK** → **[↶⊙]**

### Listening to messages using the base unit

When new messages have been recorded, **[▶]** on the base unit flashes. Press **[▶]**.

- If new messages have been recorded, the base unit plays back new messages.
- If there are no new messages, the base unit plays back all messages.

#### Note:

- When the answer on indicator on the base unit flashes rapidly, the message memory is full ("Memory capacity", page 30).

## Answering System

### Operating the answering system

Key	Operation
[▲] or [▼]	Adjust the speaker volume
[◀◀]	Repeat message (during playback) <sup>*1</sup>
[▶▶]	Skip message (during playback)
[■]	Stop playback
[X]	Erase currently playing message

\*1 If pressed within the first 5 seconds of a message, the previous message is played.

### Erasing all messages

Press [X] 2 times while the unit is not in use.

### Listening to messages using the handset

When new messages have been recorded, [M] is displayed on the handset with the total number of new messages.

- 1 [M] (middle soft key)
- 2 [▼]/[▲]: "Answer System" → **OK**
- 3 [▼]/[▲]: Select "Play New Msg." or "Play All Msg." → **OK**
- 4 When finished, press [↶].

#### Note:

- To switch to the receiver, press [↶].

### Operating the answering system

You can also operate the answering system by pressing dial keys or soft keys on the handset.

[M] (middle soft key) → [▼]/[▲]: "Answer System" → **OK**

Key	Operation
[▲] or [▼]	Adjust the receiver/speaker volume
[1] or [←]	Repeat message (during playback) <sup>*1</sup>
[2] or [→]	Skip message (during playback)
[3]	Enter the "Settings" menu
[4]	Play new messages
[5]	Play all messages
[6]	Play greeting message
[7][6]	Record greeting message
[8]	Turn answering system on
[9] or [■]	Stop recording Stop playback
[0]	Turn answering system off
[*][4] <sup>*2</sup>	Erase currently playing message
[*][5]	Erase all messages
[*][6]	Erase greeting message

\*1 If pressed within the first 5 seconds of a message, the previous message is played.


\*2 You can also erase as follows:

[X] → [▼]/[▲]: "Yes" → **OK**




## Answering System

### Erasing all messages


- 1  (middle soft key)
- 2 **[▼]/[▲]**: "Answer System" → **OK**
- 3 **[▼]/[▲]**: "Erase Message" → **OK**
- 4 **[▼]/[▲]**: "Erase All" → **OK**
- 5 **[▼]/[▲]**: "Yes" → **OK** → **[\*] [0]**

### Calling back (Caller ID subscribers only)

If caller information is received for the call, you can call the caller back while listening to a message.

- 1 Press  during playback.
- 2 **[▼]/[▲]**: "Call Back" → **OK**

### Editing the number before calling back

- 1 Press  during playback.
- 2 **[▼]/[▲]**: "Edit and Call" → **OK**
- 3 Edit the number. → **[↶]**

## Remote operation

Using a touch-tone phone, you can call your phone number from outside and access the unit to listen to messages or change answering system settings. The unit's voice guidance prompts you to press certain dial keys to perform different operations.


### Remote access code

A 3-digit remote access code must be entered when operating the answering system remotely. This code prevents

unauthorised parties from listening to your messages remotely.

#### Important:

- In order to operate the answering system remotely, you must first set a remote access code.

- 1  (middle soft key)
- 2 **[▼]/[▲]**: "Answer System" → **OK**
- 3 **[▼]/[▲]**: "Settings" → **OK**
- 4 **[▼]/[▲]**: "Remote Code" → **OK**
- 5 To turn on remote operation, enter the desired 3-digit remote access code.
  - To turn off remote operation, press **[\*]**.
- 6 **OK** → **[\*] [0]**

### Using the answering system remotely

- 1 Dial your phone number from a touch-tone phone.
- 2 After the greeting message starts, enter your remote access code.
  - The unit announces the number of new messages.
- 3 Follow the voice guidance prompts as necessary or control the unit using remote commands (page 34).
- 4 When finished, hang up.

### Voice guidance

During remote operation, the unit's voice guidance starts and prompts you to press **[1]** to perform a specific operation, or press **[2]** to listen to more available operations.

## Answering System

### Remote commands

You can press dial keys to access certain answering system functions without waiting for the voice guidance to prompt you.

Key	Operation
[1]	Repeat message (during playback) <sup>*1</sup>
[2]	Skip message (during playback)
[4]	Play new messages
[5]	Play all messages
[6]	Play greeting message
[7]	Record greeting message
[9]	Stop recording Stop playback
[0]	Turn answering system off
[*][4]	Erase currently playing message
[*][5]	Erase all messages
[*][6]	Erase greeting message (during greeting message playback)
[*][#]	End remote operation (or hang up)

\*1 If pressed within the first 5 seconds of a message, the previous message is played.

### Turning on the answering system remotely

If the answering system is off, you can turn it on remotely.

- 1 Dial your phone number from a touch-tone phone.
- 2 Let the phone ring 20 times.
  - A long beep is heard.

- 3 Enter your remote access code within 10 seconds after the long beep.
  - The greeting message is played back.
  - You can either hang up, or enter your remote access code again and begin remote operation (page 33).

### Skipping the greeting message to leave a message

You can leave a message just as any outside caller can. Call your phone number from a touch-tone phone. When the answering system picks up, press [\*] to skip the greeting message and record your message after the beep.

## Answering system settings

### Number of rings before the unit answers a call

You can change the number of times the phone rings "Number of Rings" before the unit answers a call. You can select 2 to 7 rings, or "Auto". The default setting is "4 Rings".  
 "Auto": The unit's answering system answers at the end of the 2nd ring when new messages have been recorded, or at the end of the 5th ring when there are no new messages. If you call your phone from outside to listen to new messages (page 33), you know that there are no new messages when the phone rings for the 3rd time. You can then hang up without being charged for the call.

- 1  (middle soft key)

## Answering System

- 2 [▼]/[▲]: "Answer System" → **OK**
- 3 [▼]/[▲]: "Settings" → **OK**
- 4 [▼]/[▲]: "Number of Rings" → **OK**
- 5 [▼]/[▲]: Select the desired setting.  
→ **OK** → [↻○]

### For voice mail service subscribers

To receive voice mail and use answering system properly, please note the following:

- To use the voice mail service (page 36) provided by your service provider/telephone company rather than the unit's answering system, turn off the answering system (page 30).
- To use this unit's answering system rather than the voice mail service provided by your service provider/telephone company, please contact your service provider/telephone company to deactivate your voice mail service.

If your service provider/telephone company cannot do this:

- Set this unit's "Number of Rings" setting so that this unit's answering system answers calls before the voice mail service of your service provider/telephone company does. It is necessary to check the number of rings required to activate the voice mail service provided by your service provider/telephone company before changing this setting.
- Change the number of rings of the voice mail service so that the answering system can answer the call first. To do so, contact your service provider/telephone company.

### Caller's recording time

You can change the maximum message recording time allotted to each caller. You can also select "Greeting Only" which sets the unit to greet callers but not record messages. The default setting is "3 Minutes".

- 1 [☐] (middle soft key)
- 2 [▼]/[▲]: "Answer System" → **OK**
- 3 [▼]/[▲]: "Settings" → **OK**
- 4 [▼]/[▲]: "Recording Time" → **OK**
- 5 [▼]/[▲]: Select the desired setting.  
→ **OK** → [↻○]

#### Note:

- You may create your own greeting-only message by following the steps on page 31.  
The unit plays the pre-recorded greeting-only message asking callers to call again if your own greeting-only message is not recorded.


### Call screening

You can set the call screening feature "On" or "Off". For details, see page 30. The default setting is "On".


- 1 [☐] (middle soft key)
- 2 [▼]/[▲]: "Answer System" → **OK**
- 3 [▼]/[▲]: "Settings" → **OK**
- 4 [▼]/[▲]: "Call Screening" → **OK**
- 5 [▼]/[▲]: Select the desired setting.  
→ **OK** → [↻○]

## Voice Mail Service

### Voice mail service

Voice mail is an automatic answering service offered by your service provider/telephone company. After you subscribe to this service, your service provider/telephone company's voice mail system answers calls for you when you are unavailable to answer the phone or when your line is busy. Messages are recorded by your service provider/telephone company, not your telephone. When you have new messages,  is displayed on the handset depending on your service provider/telephone company. Please contact your service provider/telephone company for details of this service.

#### Important:

- If  still remains on the display even after you have listened to new messages, turn it off by pressing and holding **[C/⊗]** for 2 seconds.
- To use the voice mail service provided by your service provider/telephone company rather than the unit's answering system, turn off the answering system (page 30). For details, see page 35. (KX-TG7321/KX-TG7322/KX-TG7323/KX-TG7324)

## Intercom

Intercom calls can be made between handsets.

**Note:**

- If you receive an outside call while talking on the intercom, you hear interrupt tones.  
To answer the call, press [**ⓧ**], then press [**↶**].
- When paging the handset for an intercom call, the paged handset beeps for 1 minute.

### Making an intercom call

- 1 [**INT**]
- 2 To page a specific handset, enter the handset number.  
• To stop paging, press [**ⓧ**].
- 3 When you finish talking, press [**ⓧ**].

### Answering an intercom call

- 1 Press [**↶**] to answer the page.
- 2 When you finish talking, press [**ⓧ**].

**Note:**

- Even when the ringer volume for outside calls is set to off (page 23), the handset rings at a low level for intercom calls.

## Transferring calls

Outside calls can be transferred between 2 handsets.

- 1 During an outside call, press [**INT**] to put the call on hold.
- 2 Enter the desired handset number you want to transfer to.
- 3 Wait for the paged party to answer.
  - If the paged party does not answer, press [**INT**] to return to the outside call.
- 4 To complete the transfer, press [**ⓧ**].
  - The outside call is routed to the handset.

### Transferring a call without speaking to the other handset user

- 1 During an outside call, press [**INT**].  
→ Enter the desired handset number.
  - **↶** flashes to indicate the outside call is on hold.
- 2 [**ⓧ**].
  - The outside call rings at the other handset.

**Note:**

- If the other handset user does not answer the call within 1 minute, the call rings at your handset again.

### Answering a transferred call

Press [**↶**] to answer the page.

**Note:**

- After the paging party disconnects, you can talk to the outside caller.

## Intercom/Locator

### Conference calls

2 handsets can have a conference call with an outside party. The following 2 methods are available:

- Another person presses [**⏪**] while one person is talking with an outside party ("Call share", page 19).
- One person pages another person during an outside call as follows.  
(KX-TG7321/KX-TG7322/  
KX-TG7323/KX-TG7324)

- 1** During an outside call, press [**INT**] to put the call on hold.
- 2** Enter the desired handset number you want to transfer to.
- 3** Wait for the paged party to answer.
  - If the paged party does not answer, press [**INT**] to return to the outside call.
- 4** To establish a conference call, press [**3**].
  - To leave the conference, press [**⏪**]. The other parties can continue the conversation.

### Handset locator

You can locate a misplaced handset by paging it.

- 1 Base unit:**  
Press [**⏪**].
  - All registered handsets beep for 1 minute.
- 2 To stop paging:**  
**Base unit:**  
Press [**⏪**].  
**Handset:**  
Press [**⏪**].

**Note:**

- Even when the ringer volume for outside calls is set to off (page 23), the handset rings at a high level for paging.

**Useful Information**

**Character entry**

The dial keys are used to enter characters and numbers. Each dial key has multiple characters assigned to it. The available character entry modes are Alphabet (ABC), Numeric (0-9), Greek (ABΓ), Extended 1 (AÄÅ), Extended 2 (ŠŠŠ), and Cyrillic (АБВ). When in these entry modes except Numeric, you can select which character is entered by pressing a dial key repeatedly.

- Press [◀] or [▶] to move the cursor.
- Press dial keys to enter characters and numbers.
- Press [C/⌫] to erase the character or number highlighted by the cursor. Press and hold [C/⌫] to erase all characters or numbers.
- Press [✱] to switch between uppercase and lowercase.
- To enter another character located on the same dial key, press [▶] to move the cursor to the next space, then press the appropriate dial key.

**Character entry modes**

Several character entry modes can be used when entering text. The characters that can be entered depend on the entry mode.

**Characters available in each character entry mode**

When the unit displays the character entry screen:

**1/▲/2** (right soft key) → [▼]/[▲]: Select a character entry mode. → **OK**

**Alphabet character table (ABC)**

0	1	ABC 2	DEF 3	GHI 4	JKL 5	MNO 6	PQRS 7	TUV 8	WXYZ 9
Space # 0	Space # & ' ( ) * , - . / 1	A B C 2	D E F 3	G H I 4	J K L 5	M N O 6	P Q R S 7	T U V 8	W X Y Z 9
		a b c 2	d e f 3	g h i 4	j k l 5	m n o 6	p q r s 7	t u v 8	w x y z 9

**Numeric entry table (0-9)**

0	1	ABC 2	DEF 3	GHI 4	JKL 5	MNO 6	PQRS 7	TUV 8	WXYZ 9
0	1	2	3	4	5	6	7	8	9

**Greek character table (ABΓ)**

0	1	ABC 2	DEF 3	GHI 4	JKL 5	MNO 6	PQRS 7	TUV 8	WXYZ 9
Space # 0	Space # & ' ( ) * , - . / 1	A B Γ 2	Δ E Z 3	H Θ I 4	K Λ M 5	N Ξ O 6	Π P Σ 7	T Υ Φ 8	X Ψ Ω Ξ 9

**Useful Information**

**Extended 1 character table (AÄÅ)**

0	1	ABC2	DEF3	GHI4	JKL5	MNO6	PQRS7	TUV8	WXYZ9
Space # 0	Space # & ' ( ) * , - . / 1	A Ä Å Á Ā Ã Ä Æ B C Ç 2	D E È É Ê Ë Ë F 3	G Ğ H I Ì Í Î Ï 4	J K L 5	M N Ñ O Ö Ó Ô Õ Ö ø 6	P Q R S Ş ß 7	T U Ü Ú Û Ü Û V 8	W X Y Ŵ Ŷ Ÿ Z 9
		a à á â ã ä å æ b c ç 2	d e è é ê ë ë f 3	g ğ h i ì í î ï 4	j k l 5	m n ñ o ö ó ô õ ö ø 6	p q r s ş ß 7	t u ü ú û ü ü v 8	w x y ŵ ŷ Ź Z 9

- The following are used for both uppercase and lowercase: ø Ş Ŵ Ŷ Ź

**Extended 2 character table (ŠŠš)**

0	1	ABC2	DEF3	GHI4	JKL5	MNO6	PQRS7	TUV8	WXYZ9
Space # 0	Space # & ' ( ) * , - . / 1	A Ä Å A B C C Ć 2	D Ď E É Ě ě F 3	G H I Í 4	J K L L Ľ ĺ 5	M N Ń Ň O Ó Ŏ Ő 6	P Q R Š Ŕ Š Ś š 7	T Ť U Ú Ů ů ú v 8	W X Y ŷ Ź Ž ž Z 9
		a á ä A b c C Ć 2	d ě e é ě ě f 3	g h i Í 4	j k l L Ľ 5	m n Ń ň o ó ŏ ő 6	p q r Š ŕ š ś š 7	t ť u ú ů ů v 8	w x y ŷ ŷ ž ž ž Z 9

- The following are used for both uppercase and lowercase:

A Ć Ć Ě Ľ Ľ Ľ Ń Ŕ Š Ś š ů ŷ Ž ž Ž

**Cyrillic character table (АБВ)**

0	1	ABC2	DEF3	GHI4	JKL5	MNO6	PQRS7	TUV8	WXYZ9
Space # 0	Space # & ' ( ) * , - . / 1	А Б В Г 2	Д Е Ж З 3	И Й К Л 4	М Н О П 5	Р С Т У 6	Ф Х Ц Ч 7	Ш Щ Ъ Ъ 8	Ь Э Ю Я 9



**Useful Information****Error messages**

If the unit detects a problem, one of the following messages is shown on the display.

Display message	Cause/solution
<b>Answer Sys. Full</b> * <sup>1</sup>	<ul style="list-style-type: none"> <li>● Erase unnecessary messages (page 32).</li> </ul>
<b>Check Tel Line</b>	<ul style="list-style-type: none"> <li>● The supplied telephone line cord has not been connected yet or not connected properly. Check the connections (page 13).</li> </ul>
<b>Error</b> * <sup>1</sup>	<ul style="list-style-type: none"> <li>● Recording was too short. Try again.</li> </ul>
<b>Failed</b> * <sup>1</sup>	<ul style="list-style-type: none"> <li>● Phonebook copy failed (page 22). Confirm the other handset (the receiver) is in standby mode and try again.</li> </ul>
<b>Incomplete</b> * <sup>1</sup>	<ul style="list-style-type: none"> <li>● The receiver's phonebook memory is full. Erase the unnecessary phonebook entries from the other handset (the receiver) and try again.</li> </ul>
<b>Memory Full</b>	<ul style="list-style-type: none"> <li>● The phonebook memory is full. Erase unnecessary entries (page 21).</li> <li>● Message memory is full. Erase unnecessary messages (page 32). *<sup>1</sup></li> </ul>
<b>No link to base. Reconnect AC adaptor.</b>	<ul style="list-style-type: none"> <li>● The handset has lost communication with the base unit. Move closer to the base unit and try again.</li> <li>● Unplug the base unit's AC adaptor to reset the unit. Reconnect the adaptor and try again.</li> <li>● The handset's registration may have been cancelled. Re-register the handset (page 26).</li> </ul>
<b>Use rechargeable battery.</b>	<ul style="list-style-type: none"> <li>● A wrong type of batteries such as Alkaline or Manganese was inserted. Use only the rechargeable Ni-MH batteries noted on page 5, 14.</li> </ul>
<b>You must first subscribe to Caller ID.</b>	<ul style="list-style-type: none"> <li>● You must subscribe to a Caller ID service. Once you receive caller information after subscribing to a Caller ID service, this message will not be displayed.</li> </ul>


\*<sup>1</sup> KX-TG7321/KX-TG7322/KX-TG7323/KX-TG7324

**Useful Information**

**Troubleshooting**

If you still have difficulties after following the instructions in this section, disconnect the base unit's AC adaptor and turn off the handset, then reconnect the base unit's AC adaptor and turn on the handset.

**General use**

Problem	Cause/solution
The unit does not work.	<ul style="list-style-type: none"> <li>• Make sure the batteries are installed correctly (page 14).</li> <li>• Fully charge the batteries (page 15).</li> <li>• Check the connections (page 13).</li> <li>• Unplug the base unit's AC adaptor to reset the unit and turn off the handset. Reconnect the adaptor, turn on the handset and try again.</li> <li>• The handset has not been registered to the base unit. Register the handset (page 26).</li> </ul>
I cannot hear a dial tone.	<ul style="list-style-type: none"> <li>• The base unit's AC adaptor or telephone line cord is not connected. Check the connections.</li> <li>• If you are using a splitter to connect the unit, remove the splitter and connect the unit to the wall jack directly. If the unit operates properly, check the splitter.</li> <li>• Disconnect the base unit from the telephone line and connect the line to a known working telephone. If the working telephone operates properly, contact our service personnel to have the unit repaired. If the working telephone does not operate properly, contact your service provider/telephone company.</li> </ul>
I do not know how to erase → (Missed call) from the display.	<ul style="list-style-type: none"> <li>• There are unviewed missed calls remaining. View them using the following method.</li> </ul> <ol style="list-style-type: none"> <li><b>1</b>  (middle soft key)</li> <li><b>2</b> <b>[▼]/[▲]</b>: "Caller List" → <b>OK</b></li> <li><b>3</b> Press <b>[▼]</b> to search from the most recent call, or press <b>[▲]</b> to search from the oldest call.</li> </ol>

**Useful Information**

**Programmable settings**

Problem	Cause/solution
I have changed the display language to a language I cannot read.	<ul style="list-style-type: none"> <li>Change the display language (page 17).</li> </ul>
While programming, the handset starts to ring.	<ul style="list-style-type: none"> <li>A call is being received. Answer the call and start again after hanging up.</li> </ul>
I cannot register a handset to a base unit.	<ul style="list-style-type: none"> <li>The maximum number of handsets (6) is already registered to the base unit. Cancel unused handset registrations from the base unit (page 27).</li> <li>You entered the wrong PIN. If you forget your PIN, see "I cannot remember the PIN." (page 43).</li> <li>Place the handset and the base unit away from other electrical appliances.</li> </ul>
I cannot remember the PIN.	<ul style="list-style-type: none"> <li>Change the PIN using the following method.                             <ol style="list-style-type: none"> <li> (middle soft key)</li> <li><b>[v]/[^]: "Base Unit Setup" → OK</b></li> <li><b>[v]/[^]: "Base Unit PIN" → OK</b></li> <li><b>[*][7][0][0][0]</b></li> <li>Enter the new 4-digit base unit PIN. → <b>OK</b> → <b>[*][0]</b></li> </ol> </li> </ul>

**Battery recharge**

Problem	Cause/solution
The handset beeps and/or  flashes.	<ul style="list-style-type: none"> <li>Battery charge is low. Fully charge the batteries (page 15).</li> </ul>
I fully charged the batteries, but  still flashes.	<ul style="list-style-type: none"> <li>Clean the charge contacts and charge again (page 15).</li> <li>It is time to replace the batteries (page 14).</li> </ul>
I fully charged the batteries, but the operating time seems to be shorter.	<ul style="list-style-type: none"> <li>Clean the battery ends (+, -) and the charge contacts with a dry cloth, and charge again.</li> </ul>
The handset display is blank.	<ul style="list-style-type: none"> <li>The handset is not turned on. Turn the power on (page 17).</li> </ul>

### Useful Information

#### Making/answering calls, intercom

Problem	Cause/solution
<p>☐ is flashing.</p>	<ul style="list-style-type: none"> <li>● The handset is not registered to the base unit. Register it (page 26).</li> <li>● The handset is too far from the base unit. Move closer.</li> <li>● The base unit's AC adaptor is not connected. Check the connections.</li> <li>● You are using the handset or base unit in an area with high electrical interference. Place the base unit and use the handset away from sources of interference.</li> </ul>
<p>Noise is heard, sound cuts in and out.</p>	<ul style="list-style-type: none"> <li>● You are using the handset or base unit in an area with high electrical interference. Place the base unit and use the handset away from sources of interference.</li> <li>● Move closer to the base unit.</li> <li>● If you use a DSL/ADSL service, we recommend connecting a DSL/ADSL filter between the base unit and the telephone line jack. Contact your DSL/ADSL provider for details.</li> </ul>
<p>The handset does not ring.</p>	<ul style="list-style-type: none"> <li>● The ringer volume is turned off. Adjust ringer volume (page 23).</li> </ul>
<p>The base unit does not ring.*1</p>	<ul style="list-style-type: none"> <li>● The ringer volume is turned off. Adjust ringer volume (page 24).</li> </ul>
<p>I cannot make a call.</p>	<ul style="list-style-type: none"> <li>● The handset is too far from the base unit. Move closer and try again.</li> <li>● Another unit is in use. Wait and try again later.</li> <li>● Answering system is being used.*1 Wait and try again later.</li> <li>● The key lock feature is turned on. Turn it off (page 20).</li> </ul>

\*1 KX-TG7321/KX-TG7322/KX-TG7323/KX-TG7324

**Useful Information****Caller ID**

<b>Problem</b>	<b>Cause/solution</b>
Caller information is not displayed.	<ul style="list-style-type: none"> <li>● You must subscribe to a Caller ID service. Contact your service provider/telephone company for details.</li> <li>● If your unit is connected to any additional telephone equipment, remove and plug the unit directly into the wall jack.</li> <li>● If you use a DSL/ADSL service, we recommend connecting a DSL/ADSL filter between the base unit and the telephone line jack. Contact your DSL/ADSL provider for details.</li> <li>● Other telephone equipment may be interfering with this unit. Disconnect the other equipment and try again.</li> </ul>
Caller information is slow to display.	<ul style="list-style-type: none"> <li>● Depending on your service provider/telephone company, the unit may display the caller's information at 2nd ring or later.</li> <li>● Move closer to the base unit.</li> </ul>
Time on the unit has shifted.	<ul style="list-style-type: none"> <li>● Incorrect time information from incoming Caller ID changes the time. Set the time adjustment to off (page 25).</li> </ul>

**Answering system (KX-TG7321/KX-TG7322/KX-TG7323/KX-TG7324)**

<b>Problem</b>	<b>Cause/solution</b>
The unit does not record new messages.	<ul style="list-style-type: none"> <li>● The answering system is turned off. Turn it on (page 30).</li> <li>● The message memory is full. Erase unnecessary messages (page 32).</li> <li>● The recording time is set to "Greeting only". Change the setting (page 35).</li> <li>● If you subscribe to the voice mail service, messages are recorded by your service provider/telephone company not your telephone. Change the unit's number of rings setting or contact your service provider/telephone company (page 34).</li> </ul>
My own greeting message cannot be properly heard.	<ul style="list-style-type: none"> <li>● Record your own greeting message again (page 31).</li> </ul>

**Useful Information**

Problem	Cause/solution
I cannot operate the answering system.	<ul style="list-style-type: none"> <li>Someone is using the unit. Wait for the other user to finish.</li> <li>A caller is leaving a message. Wait for the caller to finish.</li> <li>The handset is too far from the base unit. Move closer.</li> </ul>
I cannot operate the answering system remotely.	<ul style="list-style-type: none"> <li>You are entering the wrong remote access code. If you have forgotten your remote access code, enter the remote access code setting to check your current code (page 33).</li> <li>Press each key firmly.</li> <li>The answering system is turned off. Turn it on (page 34).</li> <li>You are using a rotary/pulse telephone. Try again using a touch-tone phone.</li> </ul>
While recording a greeting message or listening to messages, the unit rings and recording stops.	<ul style="list-style-type: none"> <li>A call is being received. Answer the call and try again later.</li> </ul>

**Liquid damage**

Problem	Cause/solution
Liquid or other form of moisture has entered the handset/base unit.	<ul style="list-style-type: none"> <li>Disconnect the AC adaptor and telephone line cord from the base unit. Remove the batteries from the handset and leave to dry for at least 3 days. After the handset/base unit are completely dry, reconnect the AC adaptor and telephone line cord. Insert the batteries and charge fully before use. If the unit does not work properly, contact your nearest Panasonic service centre.</li> </ul>

**Caution:**

- To avoid permanent damage, do not use a microwave oven to speed up the drying process.


**Useful Information**

**Specifications**

- **Standard:**  
DECT (Digital Enhanced Cordless Telecommunications),  
GAP (Generic Access Profile)
- **Number of channels:**  
120 Duplex Channels
- **Frequency range:**  
1.88 GHz to 1.90 GHz
- **Duplex procedure:**  
TDMA (Time Division Multiple Access)
- **Channel spacing:**  
1,728 kHz
- **Bit rate:**  
1,152 kbit/s
- **Modulation:**  
GFSK (Gaussian Frequency Shift Keying)
- **RF transmission power:**  
Approx. 10 mW (average power per channel)
- **Voice coding:**  
ADPCM 32 kbit/s
- **Power source:**  
220–240 V AC, 50 Hz
- **Power consumption**  
  - Base unit<sup>\*1</sup>:**  
Standby: Approx. 2.1 W  
Maximum: Approx. 6.0 W
  - Base unit<sup>\*2</sup>:**  
Standby: Approx. 2.3 W  
Maximum: Approx. 6.2 W
  - Charger<sup>\*3</sup>:**  
Standby: Approx. 1.0 W  
Maximum: Approx. 5.4 W
- **Operating conditions:**  
5 °C–40 °C, 20 %–80 % relative air humidity (dry)
- **Dimensions:**  
  - Base unit:** Approx. 44 mm × 143 mm × 107 mm

- Handset:** Approx. 150 mm × 48 mm × 35 mm
- Charger<sup>\*3</sup>:** Approx. 51 mm × 75 mm × 88 mm
- **Mass (weight):**  
  - Base unit<sup>\*1</sup>:** Approx. 140 g
  - Base unit<sup>\*2</sup>:** Approx. 170 g
  - Handset:** Approx. 130 g
  - Charger<sup>\*3</sup>:** Approx. 60 g
- \*1 KX-TG7301/KX-TG7302/  
KX-TG7303/KX-TG7304
- \*2 KX-TG7321/KX-TG7322/  
KX-TG7323/KX-TG7324
- \*3 KX-TG7302/KX-TG7303/  
KX-TG7304/KX-TG7322/  
KX-TG7323/KX-TG7324

- Note:**
- Design and specifications are subject to change without notice.
  - The illustrations in these instructions may vary slightly from the actual product.





### Useful Information



## Conditions of guarantee

This guarantee is in addition to and does not in any way affect any statutory or other rights of consumer purchasers. If within the applicable guarantee period, the appliance proves to be defective by reason of faulty design, workmanship or materials, we undertake subject to the following conditions to have the defective appliance (or any part or parts thereof) repaired or replaced free of charge.


1. The appliance shall have been purchased and used solely within either the UK or ROI and in accordance with standard operating instructions and the technical and/or Safety Standards required in the UK.
2. The appliance should be returned together with this guarantee and proof of date of purchase promptly on being found defective at the purchaser's risk and expense to the authorised dealer from whom the appliance was purchased or to the nearest authorised dealer. All enquires must be through such dealers.
3. This guarantee shall not apply to damage caused through fire, accident, lightning, misuse, wear and tear, neglect, incorrect adjustment or repair, to damage caused through installation, adaption, modification or use in an improper manner or inconsistent with the technical and/or safety standards required in the country where this appliance is used, or to damage occurred during transit to or from the purchaser.
4. If at any time during the guarantee period any part or parts of the appliance are replaced with a part or parts not supplied or approved by us or of an objective quality safe and suitable for the appliance, or the appliance has been dismantled or repaired by any person not authorised by us, we shall have the right to terminate this guarantee in whole or in part immediately without further notice.
5. The purchaser's sole and exclusive remedy under this guarantee against us is for the repair or replacement of the appliance or any defective part or parts and no other remedy, including, but not limited to, incidental or consequential damage or loss of whatsoever nature shall be available to the purchaser.
6. This guarantee shall not apply to batteries and any other items of limited natural life.
7. Our decision on all matters relating to complaints shall be final. Any appliance or defective part which has been replaced shall become our property.
8. The guarantee period applicable to this product shall be 12 months.



Please keep these operating instructions with your receipt.

#### Panasonic Business Systems U.K.


Receipt No. _____	Date of purchase _____
Model No. _____	Serial No. _____









**Index**


- A** Additional handsets: 26
- Alarm: 25
- Answering calls: 18
- Answering system: 30
  - Call screening: 30, 35
  - Erasing messages: 32, 34
  - Greeting only: 35
  - Listening to messages: 31, 32, 33
  - Number of rings: 34
  - Recording time: 35
  - Remote access code: 33
  - Remote operation: 33
  - Turning on/off: 30, 32, 34
- Auto talk: 18, 23
- B** Battery: 14, 15
- C** Caller ID service: 28
- Caller list: 28
- Caller list edit: 28
- Call privacy: 19
- Call share: 19
- Call waiting: 19
- Call Waiting Caller ID: 19
- Chain dial: 22
- Character entry: 39
- Conference calls: 38
- D** Date and time: 17
- Display
  - Contrast: 23
  - Language: 17
- E** Error messages: 41
- H** Handset
  - Deregistration: 27
  - Locator: 38
  - Registration: 26
- I** Intercom: 37
- K** Key lock: 20
- Keytones: 23
- M** Making calls: 18
- Missed calls: 28
- Mute: 19
- P** Pause: 18
- Phonebook: 21
- Phonebook copy: 22
- PIN: 26
- Power failure: 14
- Power on/off: 17
- R** Recall/flash: 19, 24
- Redialling: 18
- Repeater: 27
- Ringer tone: 23
- S** Speakerphone: 18
- T** Time adjustment: 23
- Transferring calls: 37
- Troubleshooting: 42
- V** Voice mail: 36
- Volume
  - Receiver: 18
  - Ringer (Base unit): 24
  - Ringer (Handset): 19, 23
  - Speaker: 12, 18
- W** Wall mounting: 16



---





## Notes





---

## Notes





**For your future reference**

We recommend keeping a record of the following information to assist with any repair under warranty.

Serial No.


Date of purchase

(found on the bottom of the base unit)


Name and address of dealer

Attach your purchase receipt here.

Customer Care Helpline Tel. No.: U.K. 0844 844 3898 / R.O.I. 01289 8333



# CE0470



**Sales Department:**

**Panasonic Business Systems U.K.**

Panasonic House, Willoughby Road, Bracknell, Berkshire, RG12 8FP

**Panasonic Communications Co., Ltd.**

1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan

**Copyright:**

This material is copyrighted by Panasonic Communications Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic Communications Co., Ltd.

© 2008 Panasonic Communications Co., Ltd. All Rights Reserved.



\*TG7301 E\*

**PNQX1034YA** CC0108DS1028

