

# Panasonic®

## System Setup Guide

---

Home Network System  
HUB

Model No. **KX-HNB600E**



### Thank you for purchasing a Panasonic product.

This document explains how to configure the hub and access it using a mobile device. These steps must be followed before you can use the system.  
For details about how to use the system, refer to the User's Guide (page 17).

Please read this document before using the unit and save it for future reference.  
For dedicated help, support, or advice, available to help you Monday - Friday, 09:00 - 23:00. For U.K., please contact us on 0330 3331112 and for Ireland 01 4475228.

## Table of Contents

---

### Introduction

Accessory information .....	3
Expanding the Panasonic Home Network System .....	4
General information .....	6

### Important Information

About this system .....	7
For your safety .....	7
Important safety instructions .....	8
Security cautions .....	8
For best performance .....	9
Other information .....	9

### Setup

Part names and functions .....	11
LED indicator .....	11
Connections .....	12
Wi-Fi® settings .....	13
Registering another mobile device .....	15
Registering other devices to the hub .....	16


### Appendix

Wireless communication range (DECT) .....	17
Accessing the User's Guide .....	17
Wall mounting .....	18
Specifications .....	20
Open source software notice .....	20
Software information .....	20
Conditions of guarantee .....	21

## Accessory information

### Supplied accessories

No.	Accessory item/Part number	Quantity
①	AC adaptor/PNLV236E0Z	1
②	Telephone line cord/PNJA1037Z (for U.K.)	1
③	Wall mounting adaptor/PNKL1049Z1	1



### Additional accessories

#### microSD card (not supplied)

A commercially-available microSD card must be inserted into the hub in order to record images from cameras. The following types of microSD cards are supported.

- microSD / SDHC card: Up to 32 GB

### Other information

- Design and specifications are subject to change without notice.
- The illustrations in these instructions may vary slightly from the actual product.

### Trademarks

- microSDHC Logo is a trademark of SD-3C, LLC.
- iPhone and iPad are trademarks of Apple Inc., registered in the U.S. and other countries.
- iPad mini is a trademark of Apple Inc., registered in the U.S. and other countries.
- Android is a trademark of Google Inc.
- Microsoft, Windows, and Internet Explorer are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Wi-Fi, WPA, and WPA2 are registered trademarks or trademarks of Wi-Fi Alliance.
- All other trademarks identified herein are the property of their respective owners.

### Notice

- The hub supports microSD and microSDHC memory cards. In this document, the term "microSD card" is used as a generic term for any of the supported cards.













































