Guide for registering a camera to the hub

1 Press and hold 【 ∙))B CAMERA 】 on the hub until the LED blinks in green.

HANDSET/LOCATOR ∙))A   CAMERA ∙))B   OTHER DEVICE ∙))C

2 Press and hold 【 ∙))B 】 on the back of the camera until the LED blinks in green.

Outdoor camera

Indoor camera ∙))B

**3** Wait for the hub to sound one long beep.

PNQW4532ZA CC0415WK0

Guide for registering a sensor or smart plug to the hub

1   **Press and hold 〔 ⋅))C OTHER DEVICE 〕 on the hub until the LED blinks in green.**

HANDSET/LOCATOR   CAMERA   OTHER DEVICE
⋅))A   ⋅))B   ⋅))C

2   **Press and hold 〔 ⋅))C 〕 until the LED blinks in green.**

Window/door sensor

Motion sensor

Smart plug

⋅))C

Window/door sensor:
The button is under the cover.

3   **Wait for the hub to sound one long beep.**